



Quick Installation Guide

Multi-Language Installation



The ETAP software interface language can be localized using the ETAP Language Update Setup. Follow the instructions in this section to enable this add-on feature.

Prerequisites & Notes

PC must have corresponding ETAP software version installed

PC Region and Language settings must match selected ETAP Language option

ETAP Activation code for specific Language

Languages available with ETAP 26.0.0 Include:

- » Chinese (CN)
- » German (DE)
- » French (FR)
- » Italian (IT)
- » Japanese (JP)
- » Korean (KO)
- » Portuguese (PT)
- » Spanish (SP)



1. Download Language Update

From [ETAP Help Center](#), download then extract ETAPLanguageUpdateSetup.zip

2. Launch Setup Wizard

Double-click extracted ETAPLanguageUpdateSetup.msi to run ETAP Language Update Setup Wizard


3. Welcome

In the Welcome page, click Next to continue.



4. ETAP License Grant and Agreement

The installation and use of ETAP is governed by the terms and conditions of the ETAP License Grant and Agreement. Check to agree to the license terms and conditions then click Next to continue.



5. Language Selection

In the Language Selection page, check the desired language(s) and click Next to continue.
(Note, the languages list may vary per release)

View System Requirements

Click to view ETAP System Requirements in selected language.

View Billboards

Click to view ETAP Feature Billboards in selected language.



6. Finish Setup Wizard

Upon completion, click Finish to close the Setup Wizard. .



7. Language Interface

Launch ETAP and toggle Language interface option to desired language. Click Yes to continue



8. Activation Code

After the update is extracted and installed, ETAP will automatically be restarted with the selected language interface. When prompted, input the corresponding ETAP Activation code to complete the process and launch the program.



You're ready to get started using ETAP.